



### 1974-75 CAMARO AIR CONDITIONING OUTLETS

Key	Description	Part No.	Qty.	Group
1	SCREW (8-18 x 7/8)	S.S.	AR	8.907
2	OUTLET, Air Side — Left	459343	1	9.262
3	HOSE (3/4 I.D. x 72 O.L.)	S.S.	AR	8.962
4	DUCT, Air Distributor — Upper	6262627	1	9.262
6	OUTLET, Air Side — Right	3998408	1	9.262
8	OUTLET, Air Centre	340445	1	9.262
9	STUD, Centre Outlet	6273332	2	9.262
10	SEAL, Air Outlet — Lower	3942649	AR	9.260
11	NUT	S.S.	AR	8.916
12	RETAINER, Air Distributor Upper Duct	3973794	1	9.262
13	GASKET, Air Distributor Upper Duct	8526398	AR	9.211
14	CLIP, Air Distributor Upper Duct	3973793	1	9.262
15	BRACKET, Air Distributor Upper Duct — To Glove Box Upper Flange	3973735	1	9.262
16	RIVET (1/8 x 1/4)	S.S.	AR	8.967
17	BRACKET, Air Distributor Upper Duct—Right	3989206	1	9.262
18	Nut	S.S.	AR	8.916
18	BRACKET, Air Distributor Upper Duct—Left	3989205	1	9.262
20	BRACKET, Air Distributor Upper Duct — To Instrument Panel	3989201	2	9.262
21	RIVET (1/8 x 1/4)	S.S.	AR	8.967
22	SCREW (10-16 x 3/8)	S.S.	AR	8.977

Key	Description	Part No.	Qty.	Group
23	OUTLET, Heater Defroster	3963721	1	9.779
24	SEAL, Heater Core Pipe	3973717	1	8.854
25	BRACKET, Heater and A/C Air Selector Duct	3973783	1	9.211
26	GASKET, Air Distributor Duct — Lower	3963784	1	9.262
27	SEAL, Air Outlet — Lower	3942649	AR	9.260
28	DUCT, Air Distributor — Lower	3963783	1	9.262
29	HOSE	S.S.	AR	8.962
30	CLIP	S.S.	AR	8.950
31	OUTLET, Air Lower — Right	331978	1	9.262
32	BOLT (7/16-20 x 2 1/2)	S.S.	AR	8.900
33	SCREW (10-16 x .875)	S.S.	AR	8.977
34	NUT (10-16)	S.S.	AR	8.900
35	FILLER, Air Lower Outlet	331979	1	9.262
36	Outlet, Air Lower — Left	331977	1	9.262
37	BOLT (7/16-20 x 2 1/2)	S.S.	AR	8.900
38	CLIP	S.S.	AR	8.950
41	OUTLET, Heater Air Distributor	3967993	1	9.786
42	SEAL, Air Outlet Lower	3942649	AR	9.260
43	DUCT, Heater Air Distributor	3967989	AR	9.786
44	DUCT, Heater and A/C Air Selector	3026061	1	9.262
45	GASKET, Heater and A/C Air Selector Duct	3963725	1	8.854
46	HOSE (2 in I.D. x 72 O.L.)	S.S.	AR	8.962